



Settings for HP DesignJet 1050C to fix "Low Memory" issue:



1. Right-click on the DesignJet 1050C and select Printing Preferences...



2. Click on Advanced tab.
3. Select ...In computer under the Process document...
4. Check Autorotate under the Save Paper.
5. Click OK.